Honor 3C LTE

User Guide

Contents

Foreword

Getting started

2 Your phone at a glance
4 Charging the battery
5 Powering on or off your phone
5 Locking and unlocking the screen
8 Getting to know your home screen
11 Status icons
12 Viewing recently used applications
12 Texting

Personalizing your phone

14 Changing the home screen style
14 Changing the wallpaper
14 Setting tones
15 Changing the font size

Calls

16 Smart dialing
16 Answering or rejecting a call
17 What you can do during a call
18 Turning on pocket mode
18 Making an emergency call
18 Using the call log

Contacts

20 Creating a contact
20 Importing or exporting contacts
21 Copying contacts
22 Searching for a contact
22 Creating a contact group
22 Sending messages or emails to a contact group

Messaging

23 Sending a text message
23 Sending a multimedia message
24 Forwarding a message
24 Deleting a message
24 Deleting a thread

Browser

25 Browsing web pages
25 Managing bookmarks
26 Setting the home page
26 Clearing your browsing history

Email

27 Adding a POP3 or IMAP email account
27 Adding an Exchange account
28 Sending an email
28 Checking your emails

Multimedia

30 Camera
33 Gallery
35 Music

Internet connection

38 Mobile data connection
38 Wi-Fi network
39 Wi-Fi hotspot

Sharing data

41 Bluetooth
42 Wi-Fi Direct
43 Connecting your phone to a computer

File Manager

45 Creating a folder
45 Searching for a file
45 Copying, cutting, and pasting a file
45 Renaming a file
46 Deleting a file
46 Creating a shortcut for a file or folder
46 Checking the storage status

Managing applications

47 Downloading applications
47 Installing an application
47 Sharing an application
48 Uninstalling an application
48 Clearing the application cache

Backup, restoration, and update

49 Backing up data to the local storage
49 Restoring data from the local storage
49 Restoring factory settings
50 Online update

Tools

51 Clock
52 Weather

Phone settings

54 Turning on or turning off airplane mode
54 Adjusting the screen brightness
54 Modifying tone settings
55 Modifying display settings
56 Turning on or turning off do not disturb mode
57 Setting the date and time
57 Changing the system language
57 Setting the PIN of your SIM card

Legal Notice

Foreword

Thank you for choosing the Honor 3C LTE smartphone!

This guide introduces you to the features and functions of your new phone. Also included are safety precautions you should be aware of, so please read this guide first before you begin using your new phone.

Symbols and definitions

	Note	Highlights important information and tips, and provides additional information.
	Caution	Indicates potential problems that may arise, such as device damage or data loss, if the proper care or attention is not given.
	Warning	Indicates a potentially hazardous situation which, if not avoided, could result in serious injury.

Getting started

Your phone at a glance



1	Headset jack	2	Proximity sensor/Ambient light sensor
3	Earpiece	4	Buttons
5	USB port	6	Microphone
7	Speaker	8	Power
9	Volume	10	Status indicator
11	Front camera	12	Flash
13	Microphone	14	Camera

Do not block the area around the ambient light and proximity sensor. When you attach a protective film to the screen, make sure it does not block the sensor.

Buttons

	Return	• Touch to return to the previous screen or exit the current application. • When you are entering text, touch to hide the onscreen keyboard.
	Home	Touch to return to the home screen.
	Menu	• Touch to display an option menu. • Touch and hold to display the list of recently used applications.

Charging the battery

You can charge the phone in either of the following ways:

- Use the provided USB cable and power adapter to connect your phone to a power socket.
- Use a USB cable to connect your phone to a computer, and touch **Charge only** on the **USB connection methods** screen.



Battery indicator

Your phone's battery level is shown on the status indicator.

- Blinking red: The battery level is lower than 2%.
- Steady red (when charging): The battery level is lower than 10%.
- Steady yellow (when charging): The battery level is higher than 10%.
- Steady green (when charging): The battery is almost or already full.

Important information about the battery

- Rechargeable batteries have a limited lifecycle and may eventually need to be replaced. If you notice significantly reduced battery life, replace the battery.

- If your phone has been running for long periods of time, especially in hot environments, heat may be pushed to the surface of the phone. If your phone is overheating, cease using it immediately and unplug it from any power source to let it cool down. Do not hold on to the phone for too long to avoid burn injuries.
- Use the original battery, power adapter, and USB cable to charge your phone. Using third-party accessories may reduce your phone's performance or pose security risks. Do not operate your phone or cover it with any object while it is charging. Do not cover the power adapter either.
- The time required to fully charge the battery depends on the ambient temperature and age of the battery.
- If your phone is low on power, it plays an alert tone and displays a message. If the battery level is extremely low, your phone automatically powers off.
- If the battery power is depleted, you may not be able to power on your phone immediately after you begin charging the battery. This is normal. Allow the battery to charge for a few minutes before attempting to power on your phone.

Powering on or off your phone

- To power on your phone, press and hold the power button.
- To power off your phone, press and hold the power button to display an option menu, and then touch **Power off** > **OK**.

Locking and unlocking the screen

Locking the screen not only prevents mistaken operations from occurring without your knowledge, but also protects your phone from unauthorized use. You can lock and unlock your screen in different ways. The pre-installed screen unlock method is used as an example in this section.

Locking the screen

- Method 1: Press the power button to manually lock the screen.
- Method 2: After being idle for a specified period of time, your phone automatically locks its screen.

To set the screen lock method, touch on the home screen. On the displayed **General** tab, touch **Screen lock**.

Unlocking the screen

If the screen is off, press the power button to turn it on. Slide your finger toward any direction to unlock the screen.



Flick up from the bottom of the lock screen to access the quick operation panel for one-touch optimization or to open commonly used applications, such as Calculator.



Getting to know your home screen

Your home screens are where you'll find all of your favorite widgets and applications. We did away with the application list to give you a more convenient and direct path to your applications. The default home screen is shown below.



1	Status bar: displays notifications and status icons. Flick down from the status bar to open the notification panel.
2	Display area: displays application icons, folders, and widgets.
3	Screen position indicator: shows the current screen's position.
4	Dock: displays frequently used applications.

Using the notification panel

Flick down from the status bar to open the notification panel.



1	Touch ⚙ to display the settings screen.
2	Touch the shortcut switches on the notification panel to turn on or turn off the functions.
3	Touch ⌄ to display the shortcut switches and touch ⊞ in the upper right corner to edit it.
4	Touch **Clear** to dismiss all notifications.
5	Touch an application to view it and flick left or right across a notification to dismiss it.

Taking a screenshot

Want to share an interesting scene in a movie or show off your new high score in a game? Take a screenshot and share away.

Press the power and volume down buttons simultaneously to take a screenshot. Then, open the notification panel and touch ⋖ to share the

screenshot. By default, screenshots are saved to the **Screenshots** folder in **Gallery**.

You can also flick down from the status bar to open the notification panel and touch > .

Auto-rotate screen

Your phone is built with a tilt sensor. If you rotate your phone when browsing a web page or viewing a photo, your screen automatically changes between landscape and portrait view. You'll also be able to enjoy tilt sensor-based applications, such as racing games.

To enable or disable the auto-rotate screen function, flick down from the status bar to open the notification panel, and touch > .

Moving an application or widget

On the home screen, touch and hold an application or widget until the phone vibrates to enter editing mode. You can then drag an application or widget to any fitting empty space.

Deleting an application or widget

On the home screen, touch and hold the application or widget you want to delete until is displayed. Drag the unwanted application or widget to to delete it.

Deleting an application icon uninstalls the application. When you delete an application icon, your phone prompts you to confirm the action. Touch **OK** to uninstall the application. Some pre-installed applications can't be uninstalled.

Organizing home screen icons using folders

1. On the home screen, drag an application onto another one to create a folder containing both of them.
2. Touch the folder to open it. You can then:
   - Touch the folder name to rename it.

- Touch ⊕ and add more items to the folder.
- Drag an icon out from the folder to remove the icon.

A folder must contain at least two items; otherwise, the folder will automatically disappear.

Status icons

	Signal strength		No signal
	Roaming		Airplane mode enabled
	Bluetooth on		Receiving location data from GPS
	Vibration mode enabled		Silence mode enabled
	Alarms enabled		Charging
	Battery full		Battery low
	Call in progress		Missed calls
	New messages		New emails
	New voicemails		Select input method
	Wi-Fi network available		Connected to a Wi-Fi network
	Uploading data		Downloading data
	Phone memory full		Upcoming events
	No SIM card found		Login or synchronization problem
	Synchronizing data		Synchronization failed
	Portable Wi-Fi hotspot on		More notifications
	Connected to a VPN		Headset plugged in

	USB debugging mode enabled		USB tethering on

Viewing recently used applications

Touch and hold to display the list of recently used applications. You can then:

- Touch an application to start it.
- Flick left or right across an application or touch on its right upper corner to dismiss it.
- Touch to clear the list.

Texting

Your phone comes with multiple text input methods. You can quickly enter text using the onscreen keyboard.

- Touch a text box to bring up the onscreen keyboard.
- To hide the onscreen keyboard, touch .

Selecting an input method

1. On the text input screen, flick down from the status bar to open the notification panel.
2. Touch to select an input method.

To change your phone's default input method, touch on the home screen. Under **All**, touch **Language & input** > **Default** to select an input method.

Editing text

Discover how to select, cut, copy, and paste text on your phone.



- **Select text**: Touch and hold the text to bring up . Then drag and to select more or less text, or touch **Select all** to select all text in a text box.
- **Copy text**: Select text and touch **Copy**.
- **Cut text**: Select text and touch **Cut**.
- **Paste text**: Touch where you want to insert the text, drag to move the insertion point, and touch **Paste** to paste the text you copied or cut.



Personalizing your phone

Changing the home screen style

Your phone supports the standard and simple home screen styles.

1. On the home screen, touch .
2. Under **All**, touch **Home screen style**.
3. Choose **Simple** or **Standard** and touch **APPLY**.

Changing the wallpaper

1. On the home screen, touch and hold a blank area to display the **Set Home Screen** dialog box.
2. Touch **Wallpapers**.
3. On the **Wallpaper** screen, you can:
   - Touch **Lock screen wallpaper** to set the wallpaper displayed on the phone lock screen.
   - Touch **Home screen wallpaper** to set the home screen wallpaper.
   - Touch **Random change** to have the home screen wallpaper change randomly at preset intervals.

Setting tones

1. On the home screen, touch .
2. Under **All**, touch **Sound**.
3. Touch **Phone ringtone** or **Default notification tone**, and choose either of the following tabs:
   - **Ringtone**: Choose from the default selection.
   - **Music**: Choose from the audio files you have saved to your phone.

4. Touch **APPLY**.

Changing the font size

1. On the home screen, touch .
2. Under **All**, touch **Display**.
3. Touch **Font size** and select a font size.

Calls

Smart dialing

You can make a call by entering the phone number on the dialer or use smart dialing that lets you quickly find contacts by entering parts of their names or numbers.

1. On the home screen, touch .
2. Enter the initials or first few letters of a contact's name, or part of the contact's phone number. Matching contacts in your phone and phone numbers in your call log are then displayed in a list.
3. From the list, select the contact you want to call.
4. To end the call, touch .

Answering or rejecting a call

When a call comes in, you can press the volume button to mute the ringtone.



- Drag right to answer the call.
- Drag left to reject the call.
- Drag up to reject the call and send the caller a message.

On the dialer screen, touch > **Call settings** > **Reject calls with SMS** to edit the message that will be sent.

What you can do during a call



1	Touch ⋮ > ⏸ to place the current call on hold, and touch ⏸ again to resume the call.
2	Touch ⋮ > 📞+ to start a three-way call. Before you use three-way calling, make sure you have subscribed to this service. For details, contact your service provider.
3	Touch ⠿ to display the dialer.
4	Touch 🔊 to use the speakerphone.
5	Touch 📵 to end the call.
6	Touch 🎤 to mute or unmute the microphone.
7	Touch ⋮ > 📝 to write a note.
8	Touch ⋮ > 👤 to view the contact list.

ⓘ To return to the call screen, flick down from the status bar to open the notification panel, and touch **Current call**.

Turning on pocket mode

Are you ever worried about missing important calls when your phone is in your pocket? Pocket mode can help out by gradually increasing the ringtone volume and vibration intensity of incoming calls.

1. On the home screen, touch .
2. Under **All**, touch **Call**.
3. Select the **Pocket mode** check box.

Making an emergency call

In the event of an emergency, you will still be able to make emergency calls without the use of a SIM card. However, you must still be under the coverage area.

1. On the home screen, touch .
2. Enter your local emergency number and touch .

You can make emergency calls even when the screen is locked. On the lock screen, touch **Emergency call**, enter your local emergency number, and touch .

Emergency calls are subject to cellular network quality, use environment, service provider policies, and local laws and regulations. Never rely solely on your phone for critical communications when emergencies occur.

Using the call log

The call log records your called, answered, and missed calls.

Adding a contact from the call log

1. On the home screen, touch .

2. From the call log, select the number you want to add as a contact, and touch .

3. Touch **Create new contact** or **Save to existing contact**.

You can also touch and hold the number you want to add, and touch **Create new contact** or **Save to existing contact**.

Deleting call records

1. On the home screen, touch .

2. Under **Dialer**, you can:

- Touch and hold a contact name or phone number, and touch **Delete entry** to delete the call record.
- Touch > **Delete call log** to delete multiple records simultaneously.

Contacts

Creating a contact

1. On the home screen, touch .
2. Touch **Create a new contact** (or touch).
3. Choose the save location for the contact.
4. Enter the contact name, phone number, and other details.
5. Touch **SAVE**.

Importing or exporting contacts

Your phone supports contact files in .vcf format only. This is the standard format for files storing contacts. Contact names, addresses, phone numbers, and other information can be saved in .vcf files.

Importing contacts from a storage device

1. On the home screen, touch .
2. Touch **Import contacts** > **Storage** (or touch > **Import/Export** > **Import from storage**).
3. Select one or more .vcf files, and touch **OK**.

Importing contacts from the SIM card

1. On the home screen, touch .
2. Touch **Import contacts** > **SIM card** (or touch > **Import/Export** > **Import from SIM card**).
3. Touch the contacts you want to import or touch **All** to select all contacts, and then touch **IMPORT**.

Importing contacts from a Bluetooth device

1. On the home screen, touch .
2. Touch **Import contacts** > **Another phone** (or touch ☰ > **Import/Export** > **Import from another phone**).
3. Select **Supports Bluetooth**, and touch **NEXT**. The phone then turns on Bluetooth and scans for Bluetooth devices.
4. Touch the Bluetooth device from which you want to import contacts.

When the two devices are paired, your phone automatically imports the .vcf file from the other device.

Exporting contacts to a storage device

1. On the home screen, touch .
2. Touch ☰ > **Import/Export** > **Export to storage**.
3. Touch **Export**.
4. Choose from where you want to export the contacts and touch **OK**.

To view the .vcf file you just exported, open **File Manager**. By default, the file is saved to the root directory of your phone's internal storage.

Exporting contacts to a SIM card

1. On the home screen, touch .
2. Touch ☰ > **Import/Export** > **Export to SIM card**.
3. Touch the contacts you want to export or touch **All** to select all contacts, and then touch **EXPORT**.
4. In the displayed dialog box, touch **OK**.

Copying contacts

You can copy contacts from a SIM card to your phone and vice versa.

1. On the home screen, touch .

2. Touch ☰ > **Settings** > **Copy contacts** and choose from where you want to copy the contacts.
3. Touch the contacts you want to copy or touch **All** to select all contacts.
4. Touch **COPY** and choose where you want to paste the contacts.

Searching for a contact

1. On the home screen, touch .
2. Enter the contact name or initials. Matching contacts are displayed as you type.

Creating a contact group

1. On the home screen, touch .
2. Under **Favorites**, touch ☰ > **New group**.
3. Name the contact group.
4. Touch **Add members**.
5. Touch the contacts you want to add to the group or touch **All** to select all contacts, and then touch **ADD**.
6. Touch **SAVE**.

Sending messages or emails to a contact group

1. On the home screen, touch .
2. Under **Favorites**, touch and hold the contact group you want to send a message or email to, and choose **Send message** or **Send email** from the displayed option menu.

You can also open the contact group and touch ✉ to send a message or @ to send an email.

Messaging

Sending a text message

1. On the home screen, touch .
2. In the list of message threads, touch .
3. Touch the recipient text box and enter the contact name or phone number. Matching contacts are displayed as you type. Select a contact.

Touch to select more contacts.

4. Write your message.
5. Touch **Send**.

Sending a multimedia message

Data usage fees may apply. For details, contact your service provider.

1. On the home screen, touch .
2. In the list of message threads, touch .
3. Touch the recipient text box and enter the contact name or phone number. Matching contacts are displayed as you type. Select a contact.

Touch to select more contacts.

4. Touch > **Add subject** and enter the message subject.
5. Write your message.
6. Touch , select the attachment type, and attach a file.

To attach more than one file to the message, touch **Slideshow**. You can touch **Remove slide** to delete the current slideshow.

7. Touch **Send**.

Forwarding a message

1. On the home screen, touch .
2. In the list of message threads, touch a contact name or phone number to view the conversation thread.
3. You can then:
   - Touch and hold the message you want to forward, and touch **Forward**.
   - Touch > **Forward** to forward multiple messages.
4. Touch the recipient text box and enter the contact name or phone number.

Touch to select more contacts.

5. Touch **Send**.

Deleting a message

1. On the home screen, touch .
2. In the list of message threads, touch a contact name or phone number to view the conversation thread.
3. Touch and hold the message you want to delete, and touch **Delete**.

Touch > **Delete** to delete multiple messages simultaneously.

Deleting a thread

1. On the home screen, touch .
2. In the list of message threads, you can:
   - Touch and hold the thread you want to delete, and touch **Delete conversation**.
   - Touch > **Delete** to delete multiple threads simultaneously.

Browser

Browsing web pages

1. On the home screen, touch .
2. Enter a website address in the address box. Your phone then displays matching websites as you type.
3. Touch the website you want to visit.

Managing bookmarks

Bookmarks let you keep track of your favorite websites. You can organize your bookmarks by placing them into different folders.

Adding a bookmark

1. On the home screen, touch .
2. On the **Browser** screen, open the web page you want to add as a bookmark.
3. Touch > **Save to bookmarks**.
4. Name the bookmark and touch **OK**.

Accessing a bookmark

1. On the home screen, touch .
2. Touch > **Bookmarks** then the **Bookmarks** tab.
3. Under **Local**, touch a bookmark.

Editing a bookmark

1. On the home screen, touch .
2. Touch > **Bookmarks** then the **Bookmarks** tab.

3. Touch and hold the bookmark you want to edit, and touch **Edit bookmark**.
4. Rename the bookmark, change the website address, or revise the account information. Then touch **OK**.

Setting the home page

1. On the home screen, touch .
2. Touch ⋮ > **Settings** > **General** > **Set homepage**.
3. From the displayed option menu, choose the web page you want to set as your home page.

Clearing your browsing history

To better protect your privacy, clear your browsing history from time to time.

1. On the home screen, touch .
2. Touch ⋮ > **Settings** > **Privacy & security**.
3. Touch **Clear history** then **OK**.

Email

Adding a POP3 or IMAP email account

Certain parameters must be set when you add a POP3 or IMAP email account. For details, contact your email service provider.

1. On the home screen, touch .
2. Touch **Others**.
3. Enter your **Email address** and **Password**, and touch **Next**.
4. Follow the onscreen instructions to configure the email account. The system then automatically connects to the server and checks server settings.

When the email account is set up, the **Inbox** screen is displayed.

To add more email accounts, touch > **Settings** > **NEW ACCOUNT** on the **Inbox** screen.

Adding an Exchange account

Exchange is an email system developed by Microsoft for internal enterprise correspondence. Some email service providers also provide Exchange accounts for individuals and families.
You may need to contact your email service provider to configure certain parameters.

1. On the home screen, touch .
2. Touch **Exchange**.
3. Enter your **Email address**, **Domain**, **Username**, and **Password**. Then, touch **Next**.

4. Follow the onscreen instructions to configure your Exchange account. The system then automatically connects to the server and checks server settings.

When your Exchange account is set up, the **Inbox** screen is displayed.

Sending an email

1. On the home screen, touch .
2. On the **Inbox** screen, touch to select an email account.
3. Touch .
4. Enter one or more recipients.

> To send the email to multiple recipients, touch **+ Cc/Bcc**. Separate different email addresses with semicolons (;).

5. Enter the subject, and write your message. Touch to upload any attachments.
6. When you are done, touch to send the email.

Checking your emails

1. On the home screen, touch .
2. On the **Inbox** screen, touch to select an email account.
3. Touch the email you want to read.
4. You can then:
   - Touch to delete it.
   - Touch to reply to it.
   - Touch to reply to all.
   - Touch to forward it.

- Flick left to go back to the previous email or flick right to skip to the next email.

Mail retrieval may be slightly delayed, depending on the network condition. On the **Inbox** screen, touch ⋮ > **Refresh** to refresh the inbox.

Multimedia

Camera

Your phone supports a variety of capture scenarios, such as scenery, portrait, and dynamic. It also supports smart, beauty, panoramic, audio control, and burst capture modes.

Capture screen



1	Touch to record a video.
2	• Touch to take a photo. • Touch and hold to take burst shots, and release your finger to stop.
3	Touch the thumbnail to view your photos and videos.
4	• Touch an object on the viewfinder to focus the camera on it. • Spread two fingers apart to zoom in or pinch them together to zoom out.
5	Touch to select a capture mode.
6	Touch to set the flash mode.

7	Touch to switch between the rear and front cameras.
8	Touch for more options.

Taking a photo

1. On the home screen, touch .
2. Frame the scene you want to capture. Let your camera focus automatically or touch the screen to focus the camera. When the camera is focused, the frame in the center of the viewfinder turns green.
3. Touch .

Shooting a video

1. On the home screen, touch .
2. Frame the scene you want to record.
3. Touch to start recording.
4. During the recording, touch an object or area to focus on it.

Touch to pause recording.

5. Touch to stop recording.

Continuous shooting

Continuous shooting allows you to record a series of dynamic images and pick the best from them.

1. On the home screen, touch .
2. Frame the scene you want to capture.
3. Touch and hold . The camera then takes up to 20 photos in rapid succession. You can stop shooting anytime by releasing your finger.

Taking a panoramic photo

1. On the home screen, touch .

2. Touch > to switch to panoramic mode.
3. Frame the scene you want to capture.
4. Touch to start shooting.
5. Follow the onscreen instructions and move your phone slowly to capture multiple photos.

Don't move your phone too fast. If you do, or you move it beyond the limits of the panoramic view, the viewfinder will turn red to notify you that the scene wasn't captured.

6. Touch to stop shooting. The camera automatically stitches the photos together to create one panoramic photograph.

Taking an audio photo

You can record a brief audio clip after you take a photo.

1. On the home screen, touch .
2. Touch > to switch to audio photo mode.
3. Frame the scene you want to capture.
4. Touch to take a photo. The phone then records an audio clip for a few seconds. Record your thoughts for the photo you've just taken.

Using HDR

High dynamic range (HDR) imaging technology improves the details in the lightest and darkest areas of photos for true-to-life quality.

1. On the home screen, touch .
2. Touch > to switch to HDR mode.
3. Frame the scene you want to capture.
4. Touch .

The front camera does not support HDR.

Taking a photo using audio control

1. On the home screen, touch .
2. Touch > to switch to audio control mode.
3. Frame the scene you want to capture. Your phone will take a photo when the surrounding noise reaches a certain decibel level.

Taking a photo with watermark

You can add the time, location, weather, and other information to the photo as watermarks.

1. On the home screen, touch .
2. Touch > to switch to watermark mode.
3. Flick left or right at the bottom of the screen to select a watermark.
4. Drag the watermark to adjust its position.
5. Frame the scene you want to capture.
6. Touch .

Setting the camera resolution

1. On the home screen, touch .
2. On the viewfinder, touch > **Camera** or **Video**.
3. Touch **Resolution**.
4. Select a resolution for photos and videos.

Gallery

Viewing photos or videos

1. On the home screen, touch .
2. Touch an album.
3. Touch a photo or video to view it in full screen mode.

When viewing a photo, pinch two fingers together to zoom out or spread them apart to zoom in.

Playing a slideshow

1. On the home screen, touch .
2. Touch an album.
3. Touch > **Slideshow** to play a slideshow of the photos in the album.
4. To stop the slideshow, touch the screen.

Editing a photo

You can adjust the photo brightness, saturation, size, and more.

1. On the home screen, touch .
2. Touch the photo you want to edit.
3. Touch > **Edit**.
4. Select a photo processing method.
5. Select a special effect, and follow the onscreen instructions to edit the photo.
6. When you are done, touch to save the changes.

Sharing a photo or video

Want to share your best shots or an amusing trick your dog just did? Simply share the photos and videos using email, Bluetooth, and more.

1. On the home screen, touch .
2. Touch an album.
3. Touch , and choose a sharing method from the displayed option menu.
4. Select the photo or video you want to share.
5. Touch **SHARE** and follow the onscreen instructions to share the photo or video.

Music

Listening to music

1. On the home screen, touch .

2. Select a category.

3. Touch the song you want to play.

4. Touch the playing song to enter the main playback interface.



1	Flick left or right to switch between the album cover and lyrics.
2	Touch ★ to add a song to your **Favorites**.
3	Touch ⇄ to switch between different playing modes (repeat the current song, repeat the playlist, shuffle, and play in sequence).
4	• Touch ▶ to play and touch ❚❚ to pause. • Touch ⏮ to go back to the previous song. • Touch ⏭ to skip to the next song.

5	Drag the slider to control the playback.
6	Touch ⋮ to display the option menu from which you can perform additional operations.
7	Touch dts to enable or disable DTS audio.

When a song is playing, touch ⌂ to exit the playback screen without stopping the song. To return to the music playback screen, open the notification panel and touch the playing song.

Creating a playlist

1. On the home screen, touch .
2. Touch **Playlists** > **Create new playlist**.
3. Touch the text box to name the playlist, and touch **Save**.
4. In the displayed dialog box, touch **OK**.
5. Select the songs you want to add.
6. Touch **ADD**.

Playing a playlist

1. On the home screen, touch .
2. Touch **Playlists**.
3. Touch and hold the playlist you want to play, and touch **Play**.

Sharing a song

1. On the home screen, touch .
2. Select a category.
3. On the song list, touch ⋮ > **Share**.
4. Select the song you want to share.
5. Touch **SHARE**.

6. From the displayed option menu, choose a file type.
7. Choose a sharing method and follow the onscreen instructions to share the song.

Internet connection

Mobile data connection

Turning on your mobile network

1. On the home screen, touch .
2. Under **All**, touch **Mobile networks**.
3. Select the **Data enabled** check box.

When you don't need to access the Internet, turn off your mobile network to save battery power and reduce mobile data usage.

Creating an APN

The Access Point Name (APN) is a necessary parameter for a phone to connect to a mobile network or send multimedia messages. It is usually automatically set after you insert a SIM card into your phone. If your phone can't connect to a mobile network using the automatically set APN, contact your service provider for the specific parameters and create a new APN.

1. On the home screen, touch .
2. Under **All**, touch **Mobile networks**.
3. Touch **Access Point Names**.
4. Touch > **New APN**.
5. Enter the access point name and other parameters.
6. Touch **SAVE**.

Wi-Fi network

Your phone can connect to Wi-Fi networks. Some public locations, such as airports and libraries, may have Wi-Fi networks available for use. Using Wi-Fi networks provided by certain Internet service providers may produce fees.

Before you use a public Wi-Fi hotspot, make sure you check and are aware of that service provider's fee policies.

Connecting to a Wi-Fi network

1. On the home screen, touch .
2. Under **All**, touch the Wi-Fi switch to turn on Wi-Fi.
3. Touch **Wi-Fi**. Your phone then scans for available Wi-Fi networks and displays them.
4. Touch the Wi-Fi network you want to connect to.
   - If the network is open, you will directly connect to it.
   - If the Wi-Fi network is encrypted, enter the password when prompted, and touch **Connect**.

Connecting to a Wi-Fi network using WPS

Wi-Fi protected setup (WPS) lets you quickly connect to a Wi-Fi network. Simply press the WPS button or enter the PIN to connect your phone to a Wi-Fi router that supports WPS.

1. On the home screen, touch .
2. Under **All**, touch the Wi-Fi switch to turn on Wi-Fi.
3. Touch **Wi-Fi**.
4. Touch > **WPS Push Button** and press the WPS button on the Wi-Fi router.

To connect to a Wi-Fi network through WPS PIN, touch > **Input WPS PIN**.

Wi-Fi hotspot

Your phone can function as a Wi-Fi hotspot for other devices, sharing its mobile data connection.

1. On the home screen, touch then the **All** tab.

2. Under **WIRELESS & NETWORKS**, touch **More...**.
3. Touch **Tethering & portable hotspot**.
4. Select the **Portable Wi-Fi hotspot** check box to turn on Wi-Fi hotspot.
5. Touch **Portable Wi-Fi hotspot settings** > **Configure Wi-Fi hotspot**.
6. Set the Wi-Fi hotspot's name, encryption mode, and password.

   It is recommended that you set the encryption mode to WPA2PSK for better security.

7. Touch **Save**.

On the device you want to use, search for and connect to your phone's Wi-Fi network.

Sharing data

Bluetooth

Your phone is Bluetooth-capable, allowing you to connect to other Bluetooth-enabled devices for wireless data transmission. When using Bluetooth, stay within 10 meters (33 feet) of other Bluetooth devices.

Turning on or turning off Bluetooth

1. On the home screen, touch .
2. Under **All**, touch **Bluetooth** to turn on or turn off Bluetooth. After Bluetooth is turned on, is displayed on the status bar.

Turn off Bluetooth when you don't need it to save battery power.

Searching for and pairing with other Bluetooth devices

Before pairing your phone with another device, turn on Bluetooth. Your phone's name will be displayed. Select the check box next to the phone name to set your phone as discoverable to other Bluetooth devices.

1. On the home screen, touch .
2. Under **All**, touch **Bluetooth**. Your phone will then scan for other Bluetooth devices in range.
3. In the list of detected Bluetooth devices, touch a device and follow the onscreen instructions to pair with it.

To disconnect from a paired Bluetooth device, under **PAIRED DEVICES**, touch > **Unpair**.

If you can't set up a Bluetooth connection with another device, the device may not be compatible with your phone.

Sharing a file using Bluetooth

To exchange data with another Bluetooth device, enable Bluetooth on both devices and pair them with each other.

1. On the home screen, touch .
2. Touch and hold the file you want to send, and touch **Share** > **Bluetooth**.
3. Select a device.

Receiving a file using Bluetooth

When your phone receives a file transfer request, a **File transfer** dialog box will be displayed. Touch **Accept** to start receiving the file. You can open the notification panel to view the file receiving progress.

By default, received files are saved to the **bluetooth** folder in **File Manager**.

Wi-Fi Direct

Wi-Fi Direct allows two devices to connect to each other for data transmission without using any access point.

Connecting two devices using Wi-Fi Direct

1. On the home screen, touch .
2. Under **All**, touch **Wi-Fi** to turn on Wi-Fi.
3. In the Wi-Fi network list, touch **Wi-Fi direct** to scan for available devices.
4. Select a device.

Sending a file using Wi-Fi Direct

1. On the home screen, touch .
2. Touch and hold the file you want to send, and touch **Share**.
3. Touch **Wi-Fi Direct** to scan for available devices.
4. Select a device.

Receiving a file using Wi-Fi Direct

When a file comes in through Wi-Fi Direct, your phone automatically begins receiving it. You can open the notification panel to view the file receiving progress.

By default, received files are saved to the **Wi-Fi Direct** folder in **File Manager**.

Connecting your phone to a computer

MTP mode

MTP mode lets you transfer media files, such as photos, songs, and videos, between your phone and a computer. Windows Media Player 11 or later is required.

1. Use a USB cable to connect your phone to the computer.
2. On the **USB connection methods** screen, touch **Device file manager (MTP)**. The phone driver is then automatically installed on the computer.
3. After the driver is installed, open the new drive and begin transferring media files between your phone and computer. Multimedia content on your phone can only be viewed through Windows Media Player.

HiSuite mode

HiSuite is a file transfer application developed by Huawei that lets you back up, synchronize, and transfer data between your phone and computer.

1. Use a USB cable to connect your phone to the computer.
2. On the **USB connection methods** screen, touch **PC Suite (HiSuite)**. The phone driver is then automatically installed on the computer.
3. On the computer, open the new drive, double-click **HiSuiteDownLoader.exe**, and follow the onscreen instructions to install HiSuite. You can then manage your phone's data on the displayed HiSuite window.

USB flash drive mode

If a microSD card is inserted into your phone, you can use your phone as a USB flash drive and transfer files between your microSD card and computer.

1. Use a USB cable to connect your phone to the computer.
2. On the **USB connection methods** screen, touch **USB flash drive**. The phone driver is then automatically installed on the computer.
3. After the driver is installed, the computer will identify your phone as a USB flash drive. Open the new drive to view files on your microSD card.

File Manager

Creating a folder

1. On the home screen, touch .
2. Under **Local**, touch **Internal** or **SD card**.
3. Touch ☰ > **New folder**.
4. Name the folder and touch **Save**.

Searching for a file

1. On the home screen, touch .
2. Under **Local**, touch **Internal** or **SD card**.
3. Touch ☰ > **Search**.
4. Enter part or all of the file name. Search results are displayed as you type.

Copying, cutting, and pasting a file

1. On the home screen, touch .
2. Under **Local**, touch **Internal** or **SD card**.
3. Touch or .
4. Touch the file you want to copy or cut, and touch **COPY** or **CUT**.
5. Select where you want to paste the file, and touch **PASTE**.

Renaming a file

1. On the home screen, touch .
2. Under **Local**, touch **Internal** or **SD card**.

3. Touch and hold the file you want to rename, and touch **Rename**.
4. Rename the file and touch **OK**.

Deleting a file

1. On the home screen, touch .
2. Under **Local**, touch **Internal** or **SD card**.
3. Touch .
4. Select the file you want to delete, and touch **DELETE**.
5. Touch **OK**.

Creating a shortcut for a file or folder

1. On the home screen, touch .
2. Under **Local**, touch **Internal** or **SD card**.
3. Touch and hold the file or folder you want to create a shortcut for, and choose **Desktop shortcuts** from the displayed option menu.

Checking the storage status

1. On the home screen, touch .
2. Under **Local**, touch > **Storage**.
3. On the **Storage** screen, view the total and available space in your phone's internal storage or microSD card.

Managing applications

Downloading applications

A rich selection of applications are available from a variety of sources. You can:

- Download applications from Google's Play Store.
- Download applications from web pages using the browser on your phone.
- Download applications using a computer, and copy the applications to the phone.
- Connect the phone to a computer, and download applications using HiSuite or other third-party applications.

Installing an application

Play Store should be your primary download source. Applications downloaded from some other sources may be malicious or incompatible with your phone.

1. On the home screen, touch .
2. Under **Categories**, touch **Apps**.
3. In the application list, touch the application you want to install, and follow the onscreen instructions to install it.

During the installation, follow the onscreen instructions to set the application permissions to protect your phone and privacy.

Sharing an application

1. On the home screen, touch and hold the application you want to share until is displayed at the top of the screen.

2. Drag the application to .
3. On the displayed dialog box, select a sharing method and follow the onscreen instructions to share the application.

System applications can't be shared.

Uninstalling an application

1. On the home screen, touch .
2. Under **All**, touch **Manage apps**.
3. Flick to **All**, and select the application you want to uninstall.
4. Touch **Uninstall** > **OK**.

Some pre-installed applications can't be uninstalled.

Clearing the application cache

You can clear the application cache to free up the phone storage.

1. On the home screen, touch .
2. Under **All**, touch **Manage apps**.
3. Flick to **All**, and touch **Clear cache**.

Backup, restoration, and update

Backing up data to the local storage

1. On the home screen, touch **Tools** > .
2. Select or clear the **Encrypt your backup** check box. Once the backup file is encrypted, you need to enter the password to access it.
3. Touch **New backup**.
4. Select the data you want to back up, and follow the onscreen instructions to back it up.

By default, backup files are saved to the **HuaweiBackup** folder in **File Manager**.

Encrypted backup files can only be restored by **Backup** version 3.2.26 or later. To check the version you have, open **Backup**, and touch ⋮ > **Settings** > **About**.

Restoring data from the local storage

1. On the home screen, touch **Tools** > .
2. Select the backup file you want to restore. You can use the file's backup time as a reference.
3. If the backup file has been encrypted, enter the password when prompted, and touch **OK**.
4. Select the data you want to restore, and touch **RESTORE**.

Restoring factory settings

Restoring your phone to the factory settings erases all your personal data from the phone storage, including information about your

accounts, your system and application settings, and downloaded applications. Back up important data on your phone before you restore factory settings.

1. On the home screen, touch .
2. Under **All**, touch **Backup & reset**.
3. Touch **Factory data reset** > **Reset phone** > **Reset phone**. The phone will restore its factory settings and restart.

Online update

Once in a while, new updates for your phone will be available online. You will receive a notification when updates are available. Before updating, make sure your phone has enough storage space for the update package.

- Using unauthorized third-party software to update your phone may damage your phone or put your personal information at risk. It is recommended that you update through your phone's online update feature or download official update packages from Huawei's official website.
- All your data may be erased during a system update. It is recommended that you back up important data before updating your phone.

To update your phone manually, go to the home screen, touch > **Updates** > **System updates** > **Online update** to check for updates, and follow the onscreen instructions to update your phone online.

Tools

Clock

Clock lets you view the time around the world, use stopwatch or timer to keep track of time, or set alarms to wake you up in the morning.

Alarm

1. On the home screen, touch .
2. Under **Alarm**, you can:
   - Add an alarm: Touch , and set the alarm time, ringtone, how often it repeats, and more. Then touch **DONE**.
   - Turn on or turn off an alarm: Touch the switch button to the right of an alarm to turn it on or off.
   - Configure alarm settings: Touch , and set the snooze duration, whether the alarm rings in silent mode, and what the volume buttons do when pressed.
   - Delete an alarm: Touch , select the alarm you want to delete, and touch **DELETE**.

World clock

1. On the home screen, touch .
2. Under **World clock**, you can:
   - Add a city: Touch , enter a city name or choose a city from the city list, and touch the city you want to add.
   - Set your time zone: Touch to set your home time zone and system date and time.
   - Delete a city: Touch , select the city you want to delete, and touch **REMOVE**.

Stopwatch

1. On the home screen, touch .
2. On the **Stopwatch** tab, touch **Start** to start timing.
3. Touch **Lap** to record multiple times.
4. Touch **Stop** to stop the stopwatch.

Touch **Reset** to clear all stopwatch records.

Timer

1. On the home screen, touch .
2. On the **Timer** tab, rotate the dial to set the timer duration, or touch an option to quickly select a time duration.

Touch to set a tone for the timer.

3. When you are done, touch **Start** to start the timer.
4. When the timer ends, the phone plays a tone and starts overtime timing. Touch **Close** to stop the tone and reset the timer.

When the timer is running, touch **Reset** to reset it.

Weather

Weather provides you with the latest weather information for any city around the world. You can share weather information with your family and friends.

Before you use **Weather**, turn on your phone's GPS and data service.

Adding a city

Add cities to check their real-time weather information.

1. On the home screen, touch .
2. Touch > .
3. Enter a city name. Matching cities are then displayed.

4. Select the city you want to add.

In addition to your current city, you can add up to nine cities.

Setting the default city

1. On the home screen, touch .
2. Touch .
3. Touch to the right of the city you want to set as the default city.

To rearrange the cities, in the city list, touch > **Rearrange cities**.

Updating the weather

1. On the home screen, touch .
2. Flick left or right to find the city whose weather you want to update.
3. Touch to update the weather.

You can also set **Weather** to automatic update mode. Touch > > **Settings**, select **Auto update**, and set **Update interval**. Your phone will then update the weather at the interval you set.

Phone settings

Turning on or turning off airplane mode

Your phone's signal reception or transmission may interfere with an airplane's flight system. Power off your phone or switch to airplane mode as required when you are on a flight. In airplane mode, your phone's wireless features are disabled, but you can still listen to music or play games.

Use either of the following methods to turn on or turn off **Airplane mode**:

- Press and hold the power button, and touch **Airplane mode**.
- On the home screen, touch . Under **All**, touch **Airplane mode**.

When airplane mode is on, is displayed on the status bar.

Adjusting the screen brightness

1. On the home screen, touch .
2. Under **All**, touch **Display**.
3. Touch **Brightness**.
4. Drag the slider left or right to adjust the screen brightness.

You can also flick down from the status bar to open the notification panel and adjust the screen brightness using the shortcut switch.

Modifying tone settings

1. On the home screen, touch .
2. Under **All**, touch **Sound**.
3. On the **Sound** screen, you can:

- Touch **Volume** and drag the sliders to set the volume of music, ringtones, notification tones, alarms, calls, and more.
- Touch **Silent mode** to turn on or turn off silence mode.
- Select or clear the **Vibrate in silent mode** check box to set whether your phone vibrates when it is in silence mode.
- Select or clear the **Vibrate when ringing** check box to set whether your phone vibrates when you have an incoming call.
- Touch **Phone ringtone** to select a ringtone.
- Touch **Default notification tone** to set a notification tone.
- Select or clear the **DTS mode** to turn on or turn off DTS audio.
- Touch or clear the check box under **System** to turn on or turn off the notification tone or vibration when you touch or lock the screen, take a screenshot, dial a number, and more.

Modifying display settings

1. On the home screen, touch .
2. Under **All**, touch **Display**.
3. On the **Display** screen, you can:
   - Touch **Brightness** to adjust the screen brightness.
   - Touch **Color temperature** to adjust the screen color temperature. To manually adjust the color temperature, clear the **Default** check box.
   - Touch **Wallpaper** to set the lock screen and home screen wallpapers.
   - Select or clear the **Auto-rotate screen** check box to enable or disable the screen auto-rotate function. If this function is enabled, your screen's orientation will automatically change with the way you hold your phone when you perform certain operations, such as browsing a web page, viewing a picture, or writing a message.
   - Select or clear the **Sunlight readable** check box to enable or disable readability enhancement under sunlight. If this function is enabled, your

phone will adjust the screen brightness based on the ambient light and help you read better in strong light.

- Touch **Sleep** to set a screen timeout period. If idle for the specified period, your phone automatically locks its screen to save battery power.
- Touch **Daydream** to enable or disable the screen saver. If this function is enabled, the screen saver will automatically run while your phone is being charged.
- Touch **Font size** to change the display font size.
- Touch **Font style** to change the display font style.
- Touch **Pulse notification light** to enable or disable the blinking indicator when you receive notifications.

Turning on or turning off do not disturb mode

To avoid being disturbed when you need to focus on important business, turn on do not disturb mode. In do not disturb mode, your phone will ring only when you receive calls from allowed contacts. Other calls will be rejected, and message and other notification tones will be muted.

1. On the home screen, touch .
2. Under **All**, touch **Do not disturb**.
3. On the **Do not disturb** screen, you can:
   - Touch **Enable** to turn on or turn off do not disturb mode. In do not disturb mode, is displayed on the status bar.
   - Touch **Scheduled** to schedule the effective time period for do not disturb mode.
   - Touch **Allowed contacts** to add contacts whose calls you can still receive in do not disturb mode.

- Touch **Repeat calls** to enable or disable the repeat calls function. After the repeat calls function is enabled, the second call from the same number made within 3 minutes will not be muted.

Setting the date and time

1. On the home screen, touch .
2. Under **All**, touch **Date & time**.
3. On the **Date & time** screen, you can:
   - Select the **Automatic date & time** and **Automatic time zone** check boxes to use the network date and time.
   - Clear the **Automatic date & time** and **Automatic time zone** check boxes to manually set the date, time, and time zone.
   - Select or clear the **Use 24-hour format** check box to switch between the 12-hour and 24-hour formats.
   - Touch **Select date format** to select how you want the date to be displayed.

Changing the system language

1. On the home screen, touch .
2. Under **All**, touch **Language & input**.
3. Touch **Language**.
4. Select a language.

Setting the PIN of your SIM card

A personal identification number (PIN) is delivered with your SIM card to better protect your phone data. If you enable the SIM card lock, you must enter the PIN each time you turn your phone on.

Before you perform the following operations, make sure you have obtained your SIM card's PIN from your service provider.

1. On the home screen, touch .
2. Under **All**, touch **Security**.
3. Touch **Set up SIM card lock**.
4. Select the **Lock SIM card** check box.
5. Enter your PIN, and touch **OK**.
6. Touch **Change SIM PIN** to change the PIN.

The SIM card allows only a limited number of consecutive retries if an incorrect PIN is entered. If this limit is exceeded, you must enter a PIN unblocking key (PUK), which you can obtain from your service provider. The number of consecutive attempts to enter the PUK incorrectly is also limited. If this limit is exceeded, your SIM card will be permanently disabled. For details about these limits, contact your service provider.

Legal Notice

Copyright © Huawei Technologies Co., Ltd. 2014. All rights reserved.

No part of this manual may be reproduced or transmitted in any form or by any means without prior written consent of Huawei Technologies Co., Ltd. and its affiliates ("Huawei").

The product described in this manual may include copyrighted software of Huawei and possible licensors. Customers shall not in any manner reproduce, distribute, modify, decompile, disassemble, decrypt, extract, reverse engineer, lease, assign, or sublicense the said software, unless such restrictions are prohibited by applicable laws or such actions are approved by respective copyright holders.

Trademarks and Permissions

HONOR, HUAWEI, HUAWEI, and are trademarks or registered trademarks of Huawei Technologies Co., Ltd.

Android™ is a trademark of Google Inc.

LTE is a trade mark of ETSI.

The *Bluetooth*® word mark and logos are registered trademarks owned by *Bluetooth SIG, Inc.* and any use of such marks by Huawei Technologies Co., Ltd. is under license.

Other trademarks, product, service and company names mentioned may be the property of their respective owners.

Notice

Some features of the product and its accessories described herein rely on the software installed, capacities and settings of local network, and therefore may not be activated or may be limited by local network operators or network service providers.

Thus, the descriptions herein may not exactly match the product or its accessories which you purchase.

Huawei reserves the right to change or modify any information or specifications contained in this manual without prior notice and without any liability.

Third-Party Software Statement

Huawei does not own the intellectual property of the third-party software and applications that are delivered with this product. Therefore, Huawei will not provide any warranty of any kind for third party software and applications. Neither will Huawei provide support to customers who use third-party software and applications, nor be responsible or liable for the functions or performance of third-party software and applications.

Third-party software and applications services may be interrupted or terminated at any time, and Huawei does not guarantee the availability of any content or service. Third-party service providers provide content and services through network or transmission tools outside of the control of Huawei. To the greatest extent permitted by applicable law, it is explicitly stated that Huawei shall not compensate or be liable for services provided by third-party service providers, or the interruption or termination of third-party contents or services.

Huawei shall not be responsible for the legality, quality, or any other aspects of any software installed on this product, or for any uploaded or downloaded third-party works in any form, including but not limited to texts, images, videos, or software etc. Customers shall bear the risk for any and all effects, including incompatibility between the software and this product, which result from installing software or uploading or downloading the third-party works.

This product is based on the open-source Android™ platform. Huawei has made necessary changes to the platform. Therefore, this product may not support all the functions that are supported by the standard Android platform or may be incompatible with third-party software. Huawei does not provide any warranty or representation in connect with any such compatibility and expressly excludes all liability in connection with such matters.

DISCLAIMER

ALL CONTENTS OF THIS MANUAL ARE PROVIDED "AS IS". EXCEPT AS REQUIRED BY APPLICABLE LAWS, NO WARRANTIES OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE MADE IN RELATION TO THE ACCURACY, RELIABILITY OR CONTENTS OF THIS MANUAL.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL HUAWEI BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT, OR CONSEQUENTIAL DAMAGES, OR LOSS OF PROFITS, BUSINESS, REVENUE, DATA, GOODWILL SAVINGS OR ANTICIPATED SAVINGS REGARDLESS OF WHETHER SUCH LOSSES ARE FORSEEABLE OR NOT.

THE MAXIMUM LIABILITY (THIS LIMITATION SHALL NOT APPLY TO LIABILITY FOR PERSONAL INJURY TO THE EXTENT APPLICABLE LAW PROHIBITS SUCH A LIMITATION) OF HUAWEI ARISING FROM THE USE OF THE PRODUCT DESCRIBED IN THIS MANUAL SHALL BE LIMITED TO THE AMOUNT PAID BY CUSTOMERS FOR THE PURCHASE OF THIS PRODUCT.

Import and Export Regulations

Customers shall comply with all applicable export or import laws and regulations and be responsible to obtain all necessary governmental permits and licenses in order to export, re-export or import the product mentioned in this manual including the software and technical data therein.

Privacy Policy

To better understand how we protect your personal information, please see the privacy policy at http://consumer.huawei.com/privacy-policy.

This guide is for reference only. The actual product, including but not limited to the color, size, and screen layout, may vary. All statements, information, and recommendations in this guide do not constitute a warranty of any kind, express or implied.

For DTS patents, see http://patents.dts.com. Manufactured under license from DTS Licensing Limited. DTS, the Symbol, & DTS and the Symbol together are registered trademarks, and DTS Sound is a trademark of DTS, Inc. © DTS, Inc. All Rights Reserved.

Please visit http://consumer.huawei.com/en/support/hotline for recently updated hotline and email address in your country or region.

Model: H30-L02
V100R001_01